


IR400T Hook Up Instructions

Locate the "Audio Out" plugs on the back of your TV or other electronic device.



The 3.5mm end should be plugged into the back of the Able Planet transmitter along with the power cord. Be sure to turn the power on, located on the back of the transmitter.



Plug the power cord into back of transmitter.

